

Work Order ID 75778

75778

Page 1

Friday, October 28, 2011 12:33:52 PM

Item ID: D206-642-114 Accept ***N900040100*** Setup Start ***NS1***
 Revision ID: Stop ***NS2***
 Item Name: Skidtube RH
 Start Date: 10/28/2011 Start Qty: 1.00 ***1*** Cust Item ID:
 Required Date: 12/15/2011 Req'd Qty: 1.00 ***1*** Customer:
 Reference:

Approvals: Process Plan: *[Signature]* Date: 11-10-28 Tooling: _____ Date: _____
 QC: _____ Date: _____ SPC (Y/N): _____ Date: _____
 Run Start ***NR1***
 Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
Draw Nbr	Revision Nbr								
IIN-D206-642	O								
100		0.00							
100	DOCUMENT CONTROL								
DC	Memo	0.00							
Document Control	Photocopy bluefile & type labels per PPP206-642-114 CHG001 K10112 CHG002 <i>003</i>								
110		0.00							
110	Pick Kit								
Packaging	Memo	0.00							
Packaging									
120		0.00							
120	QC4- 100% Inspect kits for completeness								
QC	Memo	0.00							
Quality Control									

M.C.J. 11/11/16
W 11 12 01 (1)

[Signature] 11/12/01 (1)

W 11 12 01 (1)

B75397RH

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 75778***75778***

Page 2

Friday, October 28, 2011 12:33:52 PM

Item ID: D206-642-114 Accept ***N900040100*** Setup Start ***NS1***
Revision ID: Stop ***NS2***
Item Name: Skidtube RH
Start Date: 10/28/2011 Start Qty: 1.00 ***1*** Cust Item ID:
Required Date: 12/15/2011 Req'd Qty: 1.00 ***1*** Customer:
Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____ Run Start ***NR1***
QC: _____ Date: _____ SPC (Y/N): _____ Date: _____ Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130		0.00							
130	Packaging								<u>SP 11-12-01</u>
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPPD206-642-114 K10112 Location: _____ PPP Rev: <u>A</u>								
140		0.00							
140	QC21- Final Inspection - Work Order Release								<u>11/2/11</u> <u>[Signature]</u>
QC	Memo	0.00							
Quality Control									

11/2/001
0

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

Friday, October 28, 2011 12:33:58 PM

Page 1

Work Order ID: 75778

75778

Parent Item: D206-642-114

D206-642-114

Parent Item Name: Skidtube RH

Start Date: 10/28/2011

Required Date: 12/15/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 10.12.08 PER REV:N DD VERF:EC
11.09.23 ADDED K10112 DD VERF:EC

IPP REV:B

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D206-642-151

Manufactured

No

110

Each

0.0000

1

1

D206-642-151

75397 *Le*

Replacement Skidtube

K10112

Manufactured

No

110

Each

0.0000

1

1

K10112

75806 *Le 11/2/11*

Saddle, Skidtube 206

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries